

HPS
CONTROLS

BOILER PUMP
PUMP FOUR
PUMP THREE
PUMP TWO
PUMP ONE

CAUTION
VENT AIR FROM TOP OF PUMP
THROUGH DELTA TO
PREVENT HEARING DAMAGE

ZONE 1
RETURN

MAIN
RETURN

